



EXCESS FLOW PROTECTOR IN-LINE SERIES

Male Pipe x Female Pipe






(Arrow indicates direction of closing flow)


SPECIFICATIONS

Type Operation	In-line excess flow protector (hose break valve) Shuts off flow if it exceeds the preset rate and then allows flow at a low rate. Remains closed until pressure is equalized. Free reverse flow. All steel construction Black oxide finish	Closing Flow	Preset by factory to customer specified value (Tolerance: +20%/-0%)				
'		Max. Pressure	3,000 psi				
		Max. Tressure	5,000 psi				
		Press. Differential	50 to 100 psi				
		Fluid	General hydraulic fluid				
Material		Operating Temp.	Not Applicable				
Rated Flow	Up to 35 gpm	Seals	Not Applicable				

DIMENSIONS

Model	Inlet	Outlet	Flow Range	A Hex	В
408-02-XX	1/4 NPT	1/4 NPT	.5 — 4 GPM	3/4	2.75
408-03-XX	3/8 NPT	3/8 NPT	.5 — 8 GPM	7/8	2.75
408-04-XX	1/2 NPT	1/2 NPT	1 — 20 GPM	1 1/8	3.00
408-06-XX	3/4 NPT	3/4 NPT	2 — 35 GPM	1 3/8	3.25





All dimensions in inches